



LW640

Complete All-Terrain **Wheel Chock Set**

Information for use _____



Intention For Use

Thank you for purchasing this single set of Complete All-Terrain Wheel Chock Set from Streetwize. This wheel chock set comprises a traction wheel grip mat, ramp and wheel chock.

This wheel chock set is intended to secure your vehicle's wheel in place when parked up. It can be used on both hard and soft ground. The traction wheel grip mat can be used on soft ground to help vehicles get more traction.

It is suitable for use with vehicles that have tyre's that are less than 9 inches wide, this includes cars, vans, caravans, estate and 4x4s.

Please note, this wheel chock set is only suitable for vehicles with tyres under 9 inches. We advise that you first measure the width of your vehicle's tyres before using these mats.

Before using this wheel chock set, please read through all the information in this document. Please use this document for future reference.

Product Elements

- Ramp x 1
 - Wheel chock x 1
 - Traction wheel grip mat x 1
-

How to Use

Hard Ground

To use the wheel chock set in the hard ground, you will only need to use the ramp and wheel chock.

1. Position the ramp where you want park the rear wheel of your vehicle.
2. Drive the rear wheel of your vehicle up the ramp
3. Secure in place with the wheel chock.
4. After use, remove the wheel chock, drive away from the ramp. Then, place the ramp and wheel chock into your vehicle's boot.

Soft Ground

1. Position the traction wheel grip mat on the soft ground surface, where you want to park the rear wheel of your vehicle.
 2. Place the ramp on the top of the mat
 3. Drive the rear wheel of your vehicle up the ramp
 4. Secure in place with the wheel chock.
 5. After use, remove the wheel chock, drive away from the ramp. Then, place the ramp, mat and wheel chock into your vehicle's boot.
-

Using The Traction Wheel Grip Mat Set

1. When parking up on soft ground, position the mat where the back tyre will be positioned.
 2. Drive the rear wheels of your vehicle over the traction wheel grip mats.
 3. Turn off your vehicle and activate your vehicle's handbrake to ensure your vehicle is securely in place.
 4. After use, drive away from the grip mat. Then, place the mats into your vehicle's boot.
-

Health & Safety

- This product is not a toy. Please ensure children are supervised at all times when they are near this product.
- Do NOT use this product for anything other than its intended purpose.
- Never attempt to pull the mat when it is under your vehicle's wheel. Risk of injury.

Technical Specifications

Name	Complete all terrain wheel chock set
Supplier Code	LW640
Dimensions	71cm x 23cm



Streetwize, Ashburton Road West,
Trafford Park, Manchester, M17 1RY

For Product Support:
E: support@streetwizeaccessories.com
T: +44 (0)161 447 8597

For Trade Enquiries:
E: sales@streetwizeaccessories.com
T: +44 (0)161 447 8580

EU Regd. Address: Ace Supply Co (Europe) Ltd. D02 A098, ROI

www.streetwizeaccessories.com